

SHAFT INSTALLATION AND TRIMMING GUIDE

DOMESTIC / US WOOD SHAFTS:

CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES	
DRIVERS	G 40	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
	G 50, G 60 & G 70	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel	
	YS-Qst 65 & 75	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel	
	YS-Q 45	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
	YS-Q 55, 65 & 75	1.5"	1.0"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
	THROTTLE	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel	
	AURA RED, BLUE, GOLD & GREEN	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel	
	YS5+, YS6+, YS7+	1.0"	0.5"	Insert 2.0" only	4.0" of Tip Parallel	
	Pershing 45	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
	Pershing 55, 65 & 75	1.0"	0.5"	Insert 2.0" only	4.0" of Tip Parallel	
	#3 WOOD	G 40	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel
		G 50, G 60 & G 70	0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
		YS-Qst 65 & 75	0.5"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
YS-Q 45		0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
YS-Q 55, 65 & 75		2.0"	1.5"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
AURA RED, BLUE, GOLD & GREEN		1.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel	
YS5+, YS6+, YS7+		1.5"	1.0"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
Pershing 45		0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
Pershing 55, 65 & 75		1.5"	1.0"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
#5- #9 WOOD		G 40	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel
	G 50, G 60 & G 70	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel	
	YS-Qst 65 & 75	1.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel	
	YS-Q 45	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
	YS-Q 55, 65 & 75	2.0"	1.5"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
	AURA RED, BLUE, GOLD & GREEN	1.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel	
	YS5+, YS6+, YS7+	2.0"	1.5"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	
	Pershing 45	0.0"	0.0"	Insert 2.0" only	2.5" of Tip Parallel	
	Pershing 55, 65 & 75	2.0"	1.5"	0.5" - then Insert 2.0"	4.0" of Tip Parallel	

TOUR AD JAPAN / ASIA WOOD SHAFTS:

CLUB	PRODUCT TYPE	STD-BORE HOSEL	BLIND BORE HOSEL	THRU BORE HOSEL	NOTES
DRIVERS	TOUR AD BB	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD DI and DJ	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD EV	0.0"	0.0"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD MD QUATTROTECH	1.0"	0.5"	Insert 2.0" only	4.0" of Tip Parallel
	TOUR AD QUATTROTECH	0.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD 9003 & P9003	0.0"	0.0"	Insert 2.0" only	2.4" of Tip Parallel
	#3 WOOD	TOUR AD BB	0.5"	0.5"	0.5" - then Insert 2.0"
TOUR AD DI and DJ		0.5"	0.5"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
TOUR AD EV		0.5"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
TOUR AD MD QUATTROTECH		1.0"	1.0"	0.5" - then Insert 2.0"	4.0" of Tip Parallel
TOUR AD QUATTROTECH		0.5"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
TOUR AD 9003 & P9003		0.5"	0.5"	Insert 2.0" only	2.4" of Tip Parallel
#5- #9 WOOD		TOUR AD BB	1.0"	1.0"	0.5" - then Insert 2.0"
	TOUR AD DI and DJ	1.0"	1.0"	0.5" - then Insert 2.0"	3.0" of Tip Parallel
	TOUR AD EV	1.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD MD QUATTROTECH	2.0"	1.5"	0.5" - then Insert 2.0"	4.0" of Tip Parallel
	TOUR AD QUATTROTECH	1.0"	0.5"	Insert 2.0" only	3.0" of Tip Parallel
	TOUR AD 9003 & P9003	1.0"	0.5"	Insert 2.0" only	2.4" of Tip Parallel

* Graphite Design encourages consulting a PGA Professional or qualified club builder to help you determine the correct shaft and length for your swing profile and to meet your goals.

* Always leave a minimum of 0.5" of the parallel tip section of the shaft above the hosel. For example with a hosel depth of 1.5" and a parallel tip length of 4.0", the tip trim length should not exceed 2.0".

* Improper installation may affect the intended performance of the shaft. Warranty is for material and workmanship of our products. Improper installation voids warranty of product.



SHAFT INSTALLATION AND TRIMMING GUIDE

ALL HYBRID AND IRON SHAFTS:

CLUB	PRODUCT TYPE	15°-18°	19°-22°	23°-26°	27+	NOTES
HYBRIDS	AURA BLUE & GREEN HYBRID (.370" tip)	0.0"	0.5"	1.0"	1.5"	Tip trim then butt trim to final desired club length.
HYBRIDS	YS-Q 85 & YS+ 85 HYBRID (.370" tip)	0.0"	0.5"	1.0"	1.5"	Tip trim then butt trim to final desired club length.
HYBRIDS	YS-Q 85 & YS+ 85 HYBRID (.355" Taper Tip)	Use 42.0" shaft P/N	Use 41.5" shaft P/N	Use 41.5" shaft P/N	Use 41.0" shaft P/N	Use specific P/N- length called out, butt trim only.
HYBRIDS	TOUR AD DI-75,85,95 & 105 (.370" tip)	0.0"	0.0"	0.0"	0.0"	Butt Trim only.
HYBRIDS	TOUR AD UT 55, 65, 85, & 95 (.350" tip)	0.0"	0.0"	0.0"	0.0"	Butt Trim only.

CLUB	PRODUCT TYPE	NOTES
Irons	AURA BLUE & GREEN Iron (.370" tip with 5.0" parallel tip section) - #3-IR 1.0", #4-IR 1.5", #5-IR 2.0", #6-IR 2.5", #7-IR 3.0", #8-IR 3.5", #9-IR 4.0", #10/Wedge-IR 4.5"	
Irons	Tour AD 50 (.370" Tip OD with 1 3/8" parallel tip section) No Tipping. Insert straight in and butt trim to desired final club length.	
Irons	Tour AD 65, 75, 85, 95 (.355" Taper Tip) No Tipping. Insert straight in and butt trim to desired final club length.	
Irons	Tour AD 105 & 115 gram weights- these shafts are combo flex shafts. Please contact GDI sales at 1-888-707-6132 x324 or x321 or e-mail: sales@gdintl.com for tipping instructions.	

ALL G-TECH SHAFTS- Note that all G-Tech shafts are Combo Flex shafts.

CLUB	PRODUCT TYPE	Driver	#3 FWY Wood	#5 FWY Wood	#7-#9 FWY Wood	NOTES
WOODS	G TECH WOOD L or R FLEX	0.0"	0.5"	1.0"	1.5"	Tip trim then butt trim to final desired club length.
WOODS	G TECH WOOD A or S FLEX	0.0"	0.5"	1.0"	1.5"	Tip trim then butt trim to final desired club length.

CLUB	PRODUCT TYPE	15°-18°	19°-22°	23°-26°	27+	NOTES
HYBRIDS	G TECH IRON L or R FLEX	0.5"	1.0"	1.5"	2.0"	Tip trim then butt trim to final desired club length.
(Using Iron shaft)	G TECH IRON A or S FLEX	1.0"	1.5"	2.0"	2.5"	Tip trim then butt trim to final desired club length.

CLUB	PRODUCT TYPE	NOTES
IRONS	G TECH IRON L or R FLEX	#3-IR 0.0" #4-IR 0.5" #5-IR 1.0" #6-IR 1.5" #7-IR 2.0" #8-IR 2.5" #9-IR 3.0" #10/WG-IR 3.0" Tip trim then butt trim to final desired club length.
IRONS	G TECH IRON A or S FLEX	#3-IR 1.5" #4-IR 2.0" #5-IR 2.5" #6-IR 3.0" #7-IR 3.5" #8-IR 4.0" #9-IR 4.5" #10/WG-IR 4.5" Tip trim then butt trim to final desired club length.

- * Graphite Design encourages consulting a PGA Professional or qualified club builder to help you determine the correct shaft and length for your swing profile and to meet your goals.
- * Always leave a minimum of 0.5" of the parallel tip section of the shaft above the hosel. For example with a hosel depth of 1.5" and a parallel tip length of 4.0", the tip trim length should not exceed 2.0".
- * Improper installation may effect the intended performance of the shaft. Warranty is for material and workmanship of our products. Improper installation voids warranty of product.